

Foreword

Thank you for buying this product. Please read these instructions carefully before using it, and put the instructions away in a safe place for future reference.

Instruction

The Mini Wired Voice Amplifier integrated with amplifier and sound box, featuring stable performance, good frequency response and super convenient in use. Specially these products with a headworn microphone and excellent audio effects. These products will be your optimal production.

It is suitable for such application as teaching, flow training & visiting, present performance and sales promotion in store, supermarket or flow sales stand. The system is beautiful in small bodily form and easy to carry and operate, which makes it a wonderful aid for various activities.

Specification

Frequency Response	50Hz-12KHz
Max. output power	4W
Output impedance	4Ω
Operating Voltage	4pcs 7#1.2V Ni-Mh rechargeable batteries or 4pcs 7#1.5V Alkaline batteries
Operating temperature	-10-45°C
Charge time	6-8hours
Operating time	continued using 4-6 hours in rich state of rechargeable Ni-Mh battery or Alkaline battery

Operating instruction

1. Open the packing, remove all accessories and match them according to "Paking List".
2. Put six pieces 7# Ni-Mh batteries (or other batteries) into battery room with the correct polarity.
3. Plugging one side of the power adapter into socket of 9V/250mA or 12V/300mA and another side was plugged into the socket of AC220V/50Hz, and the indicator is red, (please turn off the volume switch potentiometer before start to charge). The indicator is green when charge fully. Lastly draw out the power adapter from socket.
4. Wearing the headworn Mic properly, and inset the connector to the "MIC IN" hole. While set the switch from "OFF" to "ON", you can hear "click", and the PW-ON is red. Then turn the volume switch potentiometer to "ON" direction, please test the sound at same time until you get ideal sound.
5. Insert the music-bearing Φ3.5 plug to AUX hole so that you can listen to music.
6. Please turn off the power to avoid power wasting.

Attention

1. Charge rechargeable batteries fully at first time use.
2. Please take out the battery if not used for a long period.
3. While the power indicator become dim, the power of battery is going to be exhausted. Please replace the battery ASAP.
4. Charge battery monthly, if longtime not use.
5. For good effects, please make sure the sound source right to the headset microphone cartridge.
6. Please don't close the Microphone cartridge to the speaker to avoid howling.

Packing List

1. One Mini voice amplifier.
2. One headworn Microphone.
3. 4-6 pcs 7# Ni-Mh rechargeable batteries.
(Only for the products with chargeable function)
4. One Operating instruction.
5. One Service card.
6. One Power adapter.
(Only for the products with chargeable function)